

REPLACEMENT MIRROR COVER INSTALLATION INSTRUCTIONS

NOTE:



- **Handle with care!**
 - Protect **Chrome Trim Pieces** from impact and excessive bending which will damage their appearance.
 - Follow this YouTube for example installation: <https://www.youtube.com/watch?v=Ty--SZrJeRc>
-

What you will need:

- Clean work area, free of airborne dust, and debris
 - Vehicle and **Chrome Trim piece**
 - Plastic trim removal tool
 - Adhesive remover
-

Step 1. Removing Manufacturer-installed Mirror Covers:

The existing mirror covers installed by the manufacturer are clipped in place.

- Insert the tip of the trim removal tool in the small space at the top of the driver's side mirror between the mirror cover and the mirror housing.
- Gently wiggle the trim removal tool to get deeper inside the gap. Pry slightly forward toward the front of the vehicle, moving along the seam without removing the tool from the gap until you feel a clip release.
- Move the tool to the bottom of the cover and insert in the seam between the cover and the housing.
- Pry gently again, until you feel another clip release.

NOTE: Some mirror covers may have more than two clips. If the mirror cap has not come loose from the mirror housing after two clips have released, move the trim removal tool to a location close to where the cap is still attached and repeat the procedure. Once the chrome mirror cap has been removed, repeat the procedure on the passenger side. *It should be a total mirror-image to the driver's side, with the same number of clips.*

***Instructions Without Removal Tool:** Grab at the point where the mirror is closest to the window and pull until it comes off.

NOTE: Some of these can take a little effort to remove, and every now and then you will break the OEM shell's clips, so make sure there is no damage or defects to your replacement piece prior to removing the OEM shells.

Step 2. Install Replacement Chrome Mirror Covers:

- Once the OEM shell is off, you will see the areas the new part attaches to. Starting at the same place you pulled to remove the OEM, slide the new piece in place and push until it snaps into place.
- NOTE: Do not be concerned with the small space between the OEM mirror and the chrome replacement piece, this same space is found on the OEM assembly.
- For image guidance please visit www.automotivechrometrim.com